

DG-100 G (ELAN)

manual pages needed for older gliders in addition to the current manual DG-100 G ELAN

page	needed for	serial No.
cover	all	DG-100 G ELAN
conc. hinged canopy	"	up to E57
11	"	"
17	up to 103	"
18	all	up to E45
23	"	up to E57
24 (April 1975)	up to 103	"
24 (April 1979)	109, 105	E1 - E57
34	all	up to E45

Diagr. 2	all	up to E57
8	"	E45
10	"	E57

No amendments on these pages

Flight Manual and Service Manual
for sailplane type

DG-100 G

Type Certificate Data Sheet No. G-- E,U
German Sailplane Data Sheet No. 301

No.:

Registration No.:

Manufacturer: Gläser-Dirks Flugzeugbau GmbH
7520 Bruchsal 4,
Im Schollengarten 19 - 20
West Germany
Telephone: 07257/1071

Owner:

This flight handbook is to be carried in the
sailplane.

Date of issue: Nov. 1977

Pages 1 through 17 and diagrams 2, 4, 5 and 6
of the original German Language "Flug- und
Betriebshandbuch DG-100 G" have been approved
by Luftfahrt-Bundesamt.

4.4 Take-offTake off check:

1. Trim weights?
2. Parachute worn correctly?
3. Pilot seat belts and shoulder harness fastened.
4. Seat back and rudder pedals adjusted?
5. All controls and instruments in easy reach?
6. Altimeter?
7. Spoilers checked for operation and locked?
8. Flight controls tested?
9. Trim set?
10. Canopy properly closed and locked?

Trim

The trim is a friction type having no notches. The friction force may be adjusted (see maintenance manual). The trim can be locked in position by tightening the green knob. This is recommended for take-off. After release, the green trim knob should be loosened so that it does not rub on the cover plate.

Take off Roll:

The location of the tow hitch near the C.G., the extraordinary aileron control, and the low lift-off speed with its reduced ground roll all combine in a controllability that effectively reduces possibility of wingdrop and ground loop. These factors also enhance crosswind performance.

Aero-Tow

Set trim full nose down.

Hold stick in resulting position and at

38 - 43 kt. (44 - 50 mph) ease stick back to lift off. On very rough surfaces, keep a tight grip on the stick. After attaining safety altitude, the gear can be retracted with a forceful operation of the gear lever. Normal tow speed is 54 - 65 kt. (62 - 75 mph). Cruising tow speed is 90 kt. (103 mph). The center of gravity tow release is used for aero tow.

4.11 Water Ballast

One 40 kg or 50 kg PVC water tank in each wing. Dump is accomplished thru a central valve in the fuselage and out of an opening behind the main gear. On the ground each wing can be drained individually by lowering the opposite wing. The dump rate in flight is about one quart per second so the amount remaining can be easily controlled.

Filling the Tanks

Close dump valve and lower a wing. Connect the supplied clear plastic tube. Fill ballast tank while observing tube. After the tank is full (as indicated by the sight tube), raise the wing and drain the water remaining in the tube. Remove the fill tube and connect hose to dump valve. Repeat for other wing. After loading ballast, level wings and check for imbalance. Correct imbalance by draining the required amount from the heavy wing.

The PVC connections should be lubed occasionally to prevent binding.

Precautions Concerning Flight with Ballast


Ambient temperatures of less than 0° C. could cause the water to freeze so dump ballast prior to encountering these conditions. Ballast raises the landing speed and increases the landing roll. It is, therefore, recommended that ballast be dumped before landing off-field.

Dump immediately in case of leak.

Maximum allowable ballast is determined by use of diagram 5

5. Assembly

1. Remove canopy. Open fuselage access cover with coin or screwdriver.
2. Clean and lube pins, bushings and the ball ends of the control rod quick-disconnects.
3. With wings in place, sight through wing spar pin bushings and align by adjusting wing tip height. Completely insert wing spar pins and turn the grips into the U-shaped keepers. Secure with safety pins.
4. Connect aileron and spoiler controls. Spoilers should be closed but not locked. To check the quick-disconnects, be sure the latch extends through the rod and protrudes on the other side. The hole must be visible. It is recommended to fit a diameter 1 mm split pin or a safety needle in the disconnected hole for split pin hole.



Close fuselage access door.

Connect waterballast cables.


5. Set the trim nose down. Set the stabilizer on, leading the lower pins into the holes bored to hold the stabilizer temporarily a few inches above the fin. Connect the elevator with the quick connect. Pull the stabilizer forward letting it down and push it back into final position. Using an 8 mm wrench (supplied with DG-100 G) tighten the front mounting bolt. Turn it so that the safety spring locks.
6. Check flight control movement.
7. Check: Main tire pressure 36 psi minimum, tail wheel tire pressure 28 psi minimum (if pneumatic)
8. Check instruments

Trim:

The friction force on the trim lever can be adjusted by removing the left cover plate and tightening or loosening the crown nut. After adjusting it replace the cotter pin (dia. 1.5 mm x 12 mm). The friction force must be more than 4 lbs. (measured with a spring scale on the knob).

Spoiler:

The short push rod in the fuselage is adjusted so that the spoilers are extended evenly and are easily locked closed. Extension out min. 140 mm, in 0 mm. It is important that the control rod ends are not unscrewed more than a maximum of 60 mm.



6.4. Inspections

Every 200 flight hours the following items are to be checked:

1. Rudder cables for wear especially near the S-shaped tube guides of the pedal adjustment mechanism. Replace worn cables with the following hardware:
Steel cable 3.2 mm diameter LN 9374 with copper NICO-PRESS sleeve 28-3-M use tool No. 51-M-850 or 63 V-XPM or 64-CGMP, use M groove.
2. Check every year all screwed connections and safety devices. Check controls for sufficient lubrication and rust prevention.

Wheel Brake:

Adjust the wheel brake occasionally. This is done at the adjustment screw at the front landing gear street above the wheel brake lever.

Landing Gear:

Clean after soft field landings. (see 4.9)

Tow Release:

Clean tow release. After a gear up landing check cable deflectors. Damaged parts must be replaced before the next take off.

6.5 Removal of Ballast Tanks

At the wing root near the main spar you will find a cord. Attach another cord of strong synthetics about 3 mm in diameter and 5 meter in length. Loosen the 4 machine screws in the FRP cover plate. Carefully withdraw tank. Remove cords from tank and attach to new tank. Pull new tank into place with cord. Replace FRP cover plate. Secure plate and cord with bolts. Test system.

6.6 Repair of Damage

Before every flight and especially after a period of non-use, a thorough ground check should be carried out. Visually check the surface for small depressions, bubbles, and other unevenness. This could be a signal that something is not right.

Contact the manufacturer immediately and, if possible, send a photo of the damage and a report by a licensed airframe mechanic. The manufacturer will be able to supply the correct advice and a repair program saving you the time and troubles of guesswork and bad tries.

Minor surface damage such as scratches, gouges, and cracks in the finish may be repaired by a licensed airframe mechanic, (See also page 31). Knowledgeable advice can also be found in the Petite Plane Patch Primer. A list of materials for the DG-100 and a check list for post-accident inspection is found on pages 27 - 29.

Repairs by the owner should not be attempted if:

- the spar flange is damaged.
- the main fittings on the wings, fuselage, or tail are torn out or if in the immediate vicinity there are white areas in the laminations.
- the parts are torn in such a way as to make repairs uncertain without the use of jigs or appliances.
- the damage is so extensive that the original shape or contour is obscured.

Cut away undamaged areas as necessary to gain access to damaged areas.

6.5 Removal of Ballast Tanks

Tie a piece of nylon cord (3 mm) diameter and at least (5 m) long, to the nylon cord sticking out of the wing root rib. Remove the three allen key screws securing the dump valve. Pull the tank and valve out carefully. Unknot the tank, tie on the new tank and pull it into place. Screw the valve and cover plate in place. Check for watertightness.

6.6 Repair of Damage

Before every flight and especially after a period of non-use, a thorough ground check should be carried out. Visually check the surface for small depressions, bubbles, and other unevenness. This could be a signal that something is not right.

Contact the manufacturer immediately and, if possible, send a photo of the damage and a report by a licensed airframe mechanic. The manufacturer will be able to supply the correct advice and a repair program saving you the time and troubles of guesswork and bad tries.

Minor surface damage such as scratches, gouges, and cracks in the finish may be repaired by a licensed airframe mechanic, (See also page 31). Knowledgeable advice can also be found in the Petite Plane Patch Primer. A list of materials for the DG-100 and a check list for post-accident inspection is found on pages 27 - 29.

Repairs by the owner should not be attempted if:

- the spar is damaged.
- the main fittings on the wings, fuselage, or tail are torn out or if in the immediate vicinity there are white areas in the laminations.
- the parts are torn in such a way as to make repairs uncertain without the use of jigs or appliances.
- the damage is so extensive that the original shape or contour is obscured.

Cut away undamaged areas as necessary to gain access to damaged areas.

6.13

Play in Control SystemsAileron:


With the stick fixed in a neutral position, the play in the aileron 188 mm from the hinge line should be ± 1.5 mm and the aileron should be neutral.

With the aileron fixed, the play in the stick at the top should be ± 3 mm.

Elevator:

With the surface fixed in neutral, the play at the stick at the top should be ± 3 mm.


Rudder: Axial play at the upper hinge max. 0,5 mm



max. 0,5 mm

Repair of the brake cable

In case of replacement it is of importance that the cable should be placed between the two parallelogram arms of the stick system (see drawing).



Placement of the cable outside the parallelogram might lead to a blockation of the steering mechanism.

adjustment
screws

cable

Diagram 2

DG-100 G all serial No's

DG-100 G ELAN appls. No. 257

empty weight C.G.

empty weight C.G.

aft of datum

[mm] [inches]

700 27.6

650 25.6

pilot weight
incl. parachute

min. 75 kg

165 lbs

empty weight C.G. Range

600 23.6

max. 117 kg

258 lbs

486

220

507

230

525

240

[lbs]

[kg]

empty weight

issued 28.12.77

Höhensteuerung
elevator control
DG-100 E




Diagramm 8

21.479

Seitensteuerung, Fahrwerk
rudder control, landing gear
DG-100




Diagramm 10

21.479

Flight Manual and Service Manual
for sailplane type

DG-100 G Elan

German Sailplane Data Sheet No. 301

No.:

Registration No.:

Manufacturer:

ELAN

Toverna Spotnega Orudja

64 275 Begunje/Gor.

Jugoslavien

Tel.: 003864/75010

Owner:

.....

.....

This flight handbook is to be carried in the
sailplane.

Date of issue: April 1979

Pages 1 through 17 and diagrams 2, 4, 5 and 6
of the original German Language "Flug- und Betriebs-
handbuch DG-100 G" have been approved by Luftfahrt-
Bundesamt.

Concerning: DG-100 and DG-100 G with hinged
canopy

Dear Sir!

One of our customers made the experience that
the opened canopy has the effect of a burning
class when the sun shine is strong.

Especially the leatherette parts might be
heated to much. We recommend to keep the canopy
closed or to cover it with a cloth.

Please file this page after the first page of
your DG-100 flight and service manual.

Yours sincerely

W. D. L.

Bruchsal 4, 2,03.1977

Contents

Ammendments	2
1. <u>Brief description</u>	3
2. <u>Operations Limitations</u>	
2.1 Airspeed limits	4
2.2 Center of gravity in flight	4
2.3 Weights	5
2.4 Loading Plan	5
2.5 Safety-links	5
2.6 Tire pressure	5
2.7 Aerobatics	6
2.8 Instrument flight (Cloud Flying)	6
2.9 Minimum required equipment	6
3. <u>Emergency Procedures</u>	
3.1 Spin recovery	7
3.2 Recovery from unintentional instrument flight conditions	7
3.3 Rain and ice	7
4. <u>Normal Operations</u>	
4.1 Preflight inspection	8
4.2 Cockpit and controls	9
4.3 Cockpit placards	10
4.4 Take off	11
4.5 Free flight	12
4.6 Spins	12
4.7 Instrument flight	13
4.8 Aerobatics	14
4.9 Approach and landing	14
4.10 Hints for the competition pilot	15
4.11 Waterballast	17

5. <u>Assembly</u>	18
6. <u>Maintenance and inspection</u>	19
6.1 Weight and Balance	19
6.2 Weight and Balance Record	21
6.3 Reference Data	21
6.4 Inspections	23
6.5 Removal of Ballast Tanks	24
6.6 Repair of Damage	24
6.7 Service and Care	25
6.8 Lubrication	25
6.9 Material List	27
6.10 Check List after Suspected Damage	28
6.11 Repair Instructions	31
6.12 Control surface massbalances	33
6.13 Play in control Systems	34
6.14 Equipment list	35
6.15 Inspection procedure for increase of <u>Diagrams</u> service time	37
Polar	1
Empty Weight C.G.	2
3 view drawing	3
Airspeed Calibration	4
Ballast chart	5
Placards	6
Circling rate of sink polar	7
Elevator control	8
Aileron and airbrake control	9
Rudder control, landing gear	10

Flight Manual DG-100 G

Amendments

No.	Page	Description	Date	Signat.
1	Maint.-m. p.18, 34 Diagr. 8	Automatic self connection for the elevator control	24.09.80	W. A.
2	Flight-m. p.9, 11 Maint.-m. p.23 Diagr. 8	Automatic trim control and wheel brake control connected to the airbrake	19.09.80 19.09.80 24.09.80	W. A.
3	Maint.-m. Diagr. 2, 10	Seat, landing gear, aileron control stops	19.09.80	W. A.
4	Maint.-m. p.18, 24	Waterballast system	24.09.80	W. A.
5	Maint.-m. p.18	Main pin securing	24.09.80	W. A.
6	Flight-m. p.9a	Single piece canopy	24.09.80	W. A.
7	Flight-m. p.4, 5, 6, 11, 12 13, 14, 15, 16	SI-units	01.06.82	W. A.
8	Content p.1a Service-m. p.37, 38	Increase of service time (TN 301/11)	May 1985	W. A.
9	Service-m. p.23, 26	Emergency release of the one piece canopy (TN 301/12)	May 1985	W. A.
10	Service-m. p.29, 35, 36	Amendments TN 301/13	May 1985	W. A.
11	Flight-m. p.7, 9a, diagr.6a	Marking of canopy emergency release and ventilation (TN 301/14)	June 1986	W. A.
12	Service-m. p.23a	Airbrakes (TN 301/18)	Oct. 1996	W. A.
13	Flight-m. p. 3, 11	Installation of an additional tow hook TN 301/19	March 1998	W. A.

Issued March 1998

2

Flight manual DG-100 G

Brief Description

1

Single-seat, high performance, Standard Class sailplane.

Construction

Wings and tail: GFRP foam-sandwich shell
GFRP roving flanged spar

Fuselage: GFRP shell

Landing gear: Retractable

Main Tire and Whell: 5.00 x 5 Internal drum brake 14.5 inches diameter. Internal drum brake. The wheel well is completely sealed and isolated from the fuselage.

Tow Hooks:

C.G.: Sonderkupplung SH 72
additional as an option: Nose release E85 installed below the instrument console only for aerotow

Cockpit:

Inflight adjustable rudder pedals. Optional inflight adjustable backrest with provision for automatic or manual parachute.

Long canopy extends far down side of fuselage for excellent visibility. Quick-disconnect instrument console.

Trim, landing gear, and spoiler controls all on left side.

Parallelogram mechanism at stick for elevator control prevents PIO's and unintentional movement of stick and elevator in turbulence.

Spoilers:

Schempp-Hirth type on upper wing surface only.

Tailplane:

Damped stabilizer-elevator T type tail with spring trimmer.

Colour:

White, registration numbers grey

Issued March 1998 TN 301/19

3

Technical Data

Wing span	=	49.2 feet	15 m
Wing area	=	118.4 square feet	11 m ²
Aspect ratio b ² /S	=	20.5	
Length	=	23 feet	7 m
Airfoil	FX 61 - 184		
	FX 60 - 126		
Water ballast	21US gal(176 lb) (80 kg) or 26 US gal (220 lb) (100 kg)		

2. Operations limitations and operational values

Flight performance group: N (LFS) Normal category

1. Airspeed Limits (I.A.S.)

Never exceed (VNE)	260 km/h	162 mph	140 kts
Maximum speed in rough air (VB)	260 km/h	162 mph	140 kts
Maneuvering (VA)	165 km/h	103 mph	89 kts
On aerotow (VT)	165 km/h	103 mph	89 kts
On winch tow (VW)	130 km/h	81 mph	70 kts
Landing gear extended	165 km/h	103 mph	89 kts
Spoilers	260 km/h	162 mph	140 kts

Full control deflection is permitted at all speeds up to maneuvering speed. At speeds in excess of maneuvering speed, control deflection should be reduced to prevent structural overloads. At maximum permissible airspeed only 1/3 of full control deflection should be used.

Maximum permissible airspeed is based on true airspeed. The airspeed indicator reads indicated airspeed. The higher the altitude, the greater the difference between true and indicated airspeed. The following table shows the indicated airspeed for V_{NE} at altitude.

	m km/h	o - 2000	3000	4000	5000	6000
		260	247	234	222	210
Altitude ft.	o - 6000	9000	12000	15000	18000	
VNE kts.	IAS	140	133	126	120	113
	mph	161	153	145	137	130

2. Center of gravity in flight

leveling means: Tail down slope of 100: 3.67 measured at top surface of aft fuselage boom.
(See weight sheet page 20)

Datum (d): Leading edge of wing at root.
Forward limit: 8.66 inches aft of datum. 220 mm
Aft limit: 14.1 inches aft of datum. 357 mm

3. Weights

Empty weight: approx. 230 kg 510 lbs
Maximum gross takeoff weight without
water ballast: 385 kg 849 lbs
With minimum 80 kg 176 lbs waterballast: 418 kg 922 lbs
Maximum weight for non-lifting parts: 265 kg 585 lbs

4. Loading PlanCockpit payload

(Pilot including parachute) max. 117 kg 258 lbs, min-75 kg 165 lbs. Pilots C.G. most forward position at max payload 492 mm, most backward position at min payload 537 mm.

Maximum allowable gross takeoff weight must be observed. It is essential to compensate for too little cockpit weight either by ballast in the pilots seat or trim weights in the trim weight holder (46.1 inches forward of datum). One 4.9 lbs. trim weight will compensate for 8 lbs. missing from the pilot seat. Seat ballast (metal or sand bags) must be securely fastened to the glider at the seat belt attachment points.

Baggage: 30 kg 66 lbs at station 230 mm (9.1 in.) aft datum.

Waterballast

Each wing tank has a capacity of 26 USgal(110 lb) (50 kg).

Maximum allowable ballast is determined by the empty weight and fuselage payload by means of Diagram 5. Both tanks should contain equal amounts of ballast.
Station 200 mm (7.9 in.) aft of datum.

5. Safety weak links

Winch launch and aero tow - 1100 ± 66 lbs., 500 ± 30 kp

6. Tire Pressure

Main wheel: 36 PSI, 2.5 bar
Tail wheel: 28 PSI, 2 bar

7. Aerobatics (only without waterballast)

The following maneuvers are approved:

1. Spins:

Entry: Start a slow pull-up. When the aircraft starts to buffet apply full back stick with rudder in the desired direction of rotation.

Recovery: Rudder in the direction opposite to rotation, pause, then ease the stick forward. When rotation stops, neutralize rudder and gently recover from dive.

A spin is not possible with the C.G. far forward, therefore, the C.G. should be mid-range when attempting spins. An aft C.G. will produce a flatter spin.

2. Loops: entry speed: 92 kt. (106 mph) 170 km/h

3. Wingovers (Stall Turns): " " " "

4. Chandelles: " " " "

8. Instrument Flight (Cloud Flying)

Approved if properly equipped (see below)

9. Minimum Required Equipment

Airspeed indicator 27 - 162 kt. (31 - 187 mph) 50-300 km/h
 green arc 35 - 89 kt. (40 - 103 mph) 65-165 km/h
 yellow arc 89 - 140 kt. (103 - 162 mph) 165-260 km/h
 red radial line 140 kt. (162 mph) 260 km/h

Airspeed indicator is to be installed so as to utilize the forward static ports.

4-piece safety belt

Altimeter, Magnetic Compass

Automatic or manual parachute or back cushion (about 3 inches thick) Cockpit placards, check list, data placards flight handbook and service manual.

Additional for instrument flight (cloud flying)

Radio (in working order)

Compass (properly compensated)

Variometer

Turn and bank indicator or gyro horizon

Experience so far has proven the airspeed indicator installation suitable for instrument flight (cloud flying)

3 Emergency procedures

3.1 Spin Recovery aileron neutral!

Rudder in the direction opposite to rotation, pause, then ease the stick forward. When rotation stops, neutralize rudder and gently recover from dive.

3.2 Recovery from unintentional Flight in Instrument Conditions (Cloud Flight)

Open the spoilers fully and maintain a speed of approximately 108 kt. (125 mph) until regaining visual flight conditions. Spinning should not be used as a rescue measure.

3.3 Rain and Ice

1. Influence on flight characteristics.

Landing speeds and stall speeds are only slightly affected. Otherwise, there is no discernable influence in flight characteristics due to rain or light icing.

2. Water ballast installation

Freezing of the water is a possibility at ambient temperatures of 0° C. (32° F.) or below so it is advisable to dump the ballast prior to encountering these conditions.

3.4 Canopy emergency release/ bail out

a) Two piece canopy:

To bail out, open the canopy a few inches and it will be blown open and tear off in the airstream.

b) Single piece canopy:

Open the canopy - opening lever and pull then the emergency release knob.


The low sides of the cockpit allows for a quick push-off exit.

4. Normal Operations


4.1 Preflight Inspection (Daily Inspection)

- a.) The aircraft surface must be free from unevenness or irregularities, blisters, depressions, or cracks in the finish. See also 6.6
- b.) All control system quick-disconnect fittings and assembly pins are to be inspected. (See also part 5)
- c.) Check for any kind of extraneous matter or objects.
- d.) Check aileron and rudder connections.
- e.) Check all control elements for security and freedom of movement.
- f.) Tow release check. Function and free of dirt.
- g.) Visual check of landing gear, wheels, and tires.
Dirt in the forks of the main gear may cause later retraction problems.

4.2 Cockpit and Controls



Single piece canopy



Canopy jettison

1. Open canopy latch
2. Pull canopy jettison knob

The spiral spring installed in the front hinge will lift the canopy as far as necessary to be blown open by the airstream.

Ground function test of the canopy jettison

Pull canopy jettison knob. The spring must lift the canopy 1 to 2 cm in the front even if the canopy latch is in its closed position.

Reassembly of the canopy

Pull canopy jettison knob to fully open position. Pull the canopy hinge to its opened position. Insert the jettison spring. Take the canopy, one person in front, one person at the rear.

Attach the canopy on the hinge and press it down. Push the canopy jettison bolt with one hand into its forward engaged position.

4.3 Cockpit Placards



Nose down



Trim

Nose up



down


Landing gear



up



Wheel Brake



Spoilers



Tow release




Canopy latch



Rudder pedal adjust



Water ballast dump



Ventilation

Flight manual DG-100 G

4.4 Take - off

Take off check:

1. Trim weights ?
2. Parachute worn correctly?
3. Pilot seat belts and shoulder harness fastened?
4. Seat back and rudder pedals adjusted?
5. All controls and instruments in easy reach?
6. Altimeter?
7. Spoilers checked for operation and locked?
8. Flight controls tested?
9. Trim set?
10. Canopy properly closed and locked?

Trim:

Automatic trim control

To adjust the trim you have to pull the small release handle at the control stick and to place the control stick in the desired position.

When you let go the release handle your aircraft is trimmed to the adjusted control stick position.

Take off Roll:

The location of the tow hitch in the fuselage centre line, the extraordinary aileron control, and the low lift-off speed with its reduced ground roll all combine in a controllability that effectively reduces possibility of wing drop and ground loop. These factors also enhance crosswind performance.

Aero-tow:

- a) If only a C.G. release is installed, then the aerotow is to be executed with this release. Set trim full nose down.
- b) If an additional tow release for aerotow is installed, only this release should be used for aerotow. Adjust the trim for aerotow so that the indicator is 2 cm (0.8 in.) behind the forward position.
- c) General: Hold stick in resulting position and at 75-80km/h (38-43kts.) (44-50mph) ease stick back to lift off. On very rough surfaces keep a tight grip on the stick. After attaining safety altitude the landing gear can be retracted with a forceful operation of the gear handle. Normal tow speed is 100-120 km/h (54-65 kts.) (62-75mph). Cruising tow speed is 165 km/h (90 kts.) (103mph).

Winch launch is only allowed at the C.G. release.

Winch Launch

Set trim full nose down.

All phases of the takeoff are normal. After reaching a safe height the stick should be pulled back slowly so that not too much speed is gained. The most comfortable winch speed is 54-60 kt. (62-68 mph), 100-110 km/h with a minimum of 49 kt. (56 mph), 90 km/h and a maximum of 70 kt. (81 mph), 130 km/h. Pull the tow release after reaching launch altitude. Do not wait for the automatic release to function.

4.5. Free Flight

Thermal Soaring

Because of the long tail moment arm the DG 100 has good directional stability. The good roll rate (3,5 sec. from 45° bank to the opposite 45° bank) provides the maneuverability to immediately compensate for irregularities in thermal or size. Quick maneuvering at very slow speeds can be done without fear of stall.

Stall Characteristics

When the DG-100 stalls it really only mushes without a distinct stall break. Full aileron control is always available. Entering the stall with more speed and a sharp pull-up will force the DG-100 to a more distinct stall break or a roll to the side. Easing up on the stick and rudder in opposition to the roll will execute a recovery without much loss of altitude. Rain has been found to have little effect on stall characteristics.

High Speed Flight

The parallelogram stick configuration adds to the stable flight characteristics of the DG-100 G. It helps reduce the possibility of pilot induced oscillations. The DG-100 G may be trimmed at any speed up to maximum. At high speeds the stick should be held at all times. Do not exceed the maximum airspeed of 140 knots.

4.6 Spins

Water ballast in both wings does not affect spin performance. Spoilers are not needed to recover from a spin. The DG-100 has no spiral dive tendency.

Inducing a spin

With the CG position forward or in the middle of the CG limits the DG-100 G will not remain in a spin regardless of stick position. Trying to induce a spin in the usual manner will result in a skid or a stall over one wing with the DG-100 G recovering after a quarter turn.

With the CG further aft the pilot can induce a spin by the standard method. Inducing the spin: gradually bring the sailplane into a stall. When it starts to burble, pull the stick back completely and kick in full rudder in the spin direction. Recovering from the spin: Opposite full rudder, pause, then ease stick forward, after the spin has stopped neutralize the controls and carefully pull off excess speed.

4.7 Instrument Flight (Cloud Flying)

Fly especially smoothly. One should not use a spin as a rescue measure. In emergency open the spoilers and maintain approximately 108 kt. (125 mph) 200 km/h until regaining visual flight conditions.

4.8 Aerobatics (only without waterballast)

Only the maneuvers listed below are approved. If the given entry speeds are observed, there will be no necessity for especially vigorous control application and high structural loads will be avoided. All maneuvers are to be done gently.

The following maneuvers are approved:

	entry speed
1. Spins	
2. Loops	(170 km/h) 92 kt. (106 mph)
3. Wingovers (Stall Turns)	(") 92 kt. (106 mph)
4. Chandelles	(") 92 kt. (106 mph)

The wingover is especially graceful when not only rudder is used but also a little aileron in the direction of turn. The amount of aileron should be reduced at the top of the maneuver.

4.9 Approach and Landing

Final approach speed in smooth air is 51 kt. (60 mph), 95 km/h. Good short field landing capability due to the high rate of descent possible with the Schempp-Hirth spoilers. The DG-100 G slips well and this can be used as an approach aid.

Low speed controllability is such that landings in even strong crosswinds are simple and routine.

The approach speed should be increased by approximately $\frac{1}{2}$ the wind velocity to protect against low level wind

shear. This extra speed can be reduced just prior to touchdown. Additionally, in gusty conditions the approach speed should be increased and this extra speed should be carried to touchdown.

The docile nature of the FX 61 - 184 airfoil will permit even a tail wheel first touchdown without the subsequent hard drop-in.

Landings in soft fields with the landing gear down are possible if the stick is held back during roll-out. Only for landings in very short fields should the landing gear be left retracted.

After a soft field landing it is important to remove dirt or other foreign matter from the retraction forks to prevent the possibility of future retraction problems. A simple hosing with water is the best cleaning method.

4.10 Hints for the Competition Pilot

A few general tips on ballast:

For lift of less than 2 kt., 1 m/s, it will be profitable to fly without ballast. This is also true for extremely weak weather or when working the weak evening lift. Medium lift of 4 kt., 2 m/s, will require about half ballast, 40 l or 11 US gal. (9 Imp. gal.). Use full ballast in lift of 6 kt., 3 m/s, or more. Maximum allowable takeoff gross weight must be observed. The maximum ballast is determined by empty weight and fuselage payload by means of Diagram 5.

While in flight, ballast may be reduced as desired by using a dump rate of approximately one quart per second, (1l/sec.)

The competition pilot will appreciate the enhanced response given by a center of gravity which lies near the aft limit.

To obtain maximum performance, the sailplane surfaces should be clean and gaps at the wing and fuselage junction and at the tail should be sealed with tape.


The polar (diagram 1) is valid only under these conditions.

An accumulation of dirt, rain etc. will degrade performance slightly.

Good instrumentation is necessary to achieve high efficiency flight. In addition to a variometer, one certainly should have a combination instrument which displays airspeed, vertical velocity, and Mc Cready values. Several "Sollfahrtgeber" instruments are available from German manufacturers. The following Mc. Cready values are computed for still air.

m/s	kt.	5.9 $\frac{\text{lbs}}{\text{sqf.}}$	29 kg/m ²	6.8 $\frac{\text{lbs}}{\text{sqf.}}$	33 kg/m ²	wing loading airspeed kts. mph, km/h
0	0	51 (59)	95	54 (62)	900	
1	2	68 (78)	125	70 (81)	130	
2	4	78 (91)	145	84 (97)	155	
3	6	90 (103)	165	96 (110)	175	
4	8	98 (112)	180	101 (117)	185	

It is easily seen from the above table that the combination instrument will yield values of sufficient accuracy at medium wing loadings.

Connection of the "Sollfahrtgeber"

4.11 Water Ballast

One eleven gallon 50 l PVC water tank in each wing. Dump is accomplished thru two valves, one in each wings bottomside near the fuselage. On the ground each wing can be drained individually by opening only one valve. The dump rate in flight is about one quart per second so the amount remaining can be easily controlled.

Filling the Tanks

For filling the Waterballast pull back the lever (top-right tank, bottom-left tank) in the cockpit. Place one wingtip on the ground. Attach the hose connection in the water outlet on the undersurface of the wing.

Fill with the desired amount of water, remove the hose and close the valve with the waterballast lever. Place the other tank.

In case the valve leaks slightly, apply some grease to the valve surfaces.

After filling the tanks, check to see if the wings are balanced. If one wing is heavy, release enough water to balance the wings.

Precautions Concerning Flight with Ballast

Ambient temperatures of less than 0° C could cause the water to freeze so dump ballast prior to encountering these conditions. Ballast raises the landing speed and increases the landing roll. It is, therefore, recommended that ballast be dumped before landing off-field.

Dump immediately in case of leak.


Maximum allowable ballast is determined by use of diagram 5.

5. Assembly and disassembly

5.1 Assembly


1. Open the canopy and open the access cover with a screwdriver.
2. Clean and lube the pins, bushings and the ball ends of the control rod quick connects.
3. With a helper on the wingtip, lead the wings into place. Sight through the wing main pin bushings to determine alignment. Push the main pins in as far as possible. Turn the handles up to the fuselage wall. Therefore pull out the white securing knob. Set the knob back in its locking position.
4. Connect aileron and spoiler controls. Spoilers are best connected in the closed but not locked position. To check the quick connects, ensure that the sliding latch has returned as far as it can locking the ball end in place.

The hole must be visible. It is recommended to fit a diameter 1 mm spring pin in the hole (500 30 771)



Attach cover plate

5. Rigging of the stabilizer with the automatic elevator control self connection mechanism. Set the trim nose down. Set the stabilizer on, so that the ball bearing at the fuselage side push rod is inserted into the funnel at the elevator. Look through the plexi-glas disc to watch the procedure. When stabilizer is set down laying on the fin push it back. The ball bearing will slide forward in the funnel if you will hold the elevator in the pertinent position. Use an 8 mm wrench (supplied with your glider) to tighten the front mounting bolt. Turn it so that the securing spring engages into the slit of the bolt.
6. Control check Check tire pressure (2,5 bar 36 psi main, 2 bar 28 psi tailwheel). Check instruments.



6. Maintenance and Inspection

6.1 Weight and Balance

Method of weighing your DG-100:

1. Assemble the glider completely with gear down.
2. Place a scale under the tailwheel.
3. The fuselage must be leveled so that the top of the aft fuselage boom has a tail-down slope of 100 : 3.67.
4. Water ballast tanks should be empty.
5. Read weight of tail wheel. W_2 .
6. Be certain the wings are level.
7. Measure the distance between perpendiculars through points a and b. (see figure, next page)

Using the Empty Weight and the values determined above, calculate the C.G. as follows:

$$\text{C.G. Empty: } X_{s \text{ empty}} = \frac{W_2 \text{ empty} \times b}{\text{Gross Weight empty}} + a$$

Weight includes all accessories but excludes pilot and parachute. Remove loose objects from cockpit.

$$\text{C.G. In Flight: } X_{s \text{ gross}} = \frac{W_2 \text{ flight} \times b}{\text{Gross weight flight}} + a$$


The flight weight includes empty weight items plus pilot, parachute, and all items needed in flight (barograph, camera, cushions, etc.). In addition, the rudder pedals and seat back should be adjusted as in flight.

Datum (d)

Wing leading edge
near root

Leveling line:

Aft fuselage boom slope
100 : 3.67 (tail down)




Repairs or alterations

After the addition or deletion of equipment or accessories repairs, painting, or any change in the aircraft that could influence the weight and balance; a new weight and balance must be computed. Aircraft certificated as Standard Category must have the weight and balance certified by a licensed Airframe Mechanic. Empty weight C.G. range is determined by reference to diagram no. 2. If the C.G. is out of limits, adjustments may be made by ballasting or by relocating equipment or accessories.

6.2 Weight and Balance Record

Maximum allowable Flight Weight

Weighed on					
Empty Weight					
Instruments					
Oxygen Equipment					
Empty Weight C.G. aft of datum	in.				
Minimum Weight in pilot seat	165 lbs				
Maximum Payload	lbs.				
Pilot with parachute, water, baggage					

6.3 Reference DataWingSweep Back = 0° Dihedral (Leading Edge, Line) = 3° Angle of incidence = 0°

Wing oscillated frequency: / min Aircraft should rest on the wheels during the frequency measurements.

Flight control Travel and ToleranceAileron:

up 102 mm + 5 mm
 down 46 mm + 5 mm
 measured 188 mm from hinge line.

If the full-travel distance is too small, the short push rod on the aileron dirve must be shortened.

Rudder:

+ 243 mm + 10 mm tolerance
 measured 460 mm from hinge line


The midpoint of rudder travel can be adjusted by letting out on one cable and taking up on the other simultaneously and in equivalent amounts.

Elevator:

Up travel 61 mm + 2 mm
 Down travel 29 mm - 1 mm
 measured 150 mm from hinge line.

The adjustment is made at the stick. To measure the displacement lay a straight edge over the elevator and trailing surface of the stabilizer. The surface is flat in this area. The straight edge must lie parallel to the stabilizer surface. Holding a measuring stick with one end on the floor mark the 0 point on the stick. Then measure the up and down displacements from this "0" point.


parallel to stabilizer surface!




measuring stick (one end on
the floor)

Trim:

The automatic trim is to adjust so that the control stick is 1 to 1,5 cm behind its forward position. The tension of the trim springs is to adjust concerning to the sketch.

Spoiler:

The short push rod in the fuselage is adjusted so that the spoilers are extended evenly and are easily locked closed. Extension out min. 140 mm, in 0 mm. It is important, that the control rod ends are not unscrewed more than a maximum of 60 mm.

6.4. Inspections

Every 200 flight hours the following items are to be checked:

1. Rudder cables for wear especially near the S-shaped tube guides of the pedal adjustment mechanism. Replace worn cables with the following hardware: Steel cable 3,2 mm diameter LN 9374 with copper NICOPRESS sleeves 28-3-M use tool No. 51-M-850 or 63 V -XPM or 64 -CGMP, use M groove.
2. Check every year all screwed connections and safety devices. Check controls for sufficient lubrication and rust prevention.

Canopy emergency release of the single piece canopy:

To be checked every 3 month referring to flight manual page 9 a.

Wheel Brake:

If the braking effect is insufficient adjust the wheel brake at the adjustment screw at the front landing gear strut above the wheel brake lever. Check that you can open the spoilers as far as to allow a slot of min. 38 mm between spoilers and wing surface when the wheel brake starts to operate.

Landing Gear: Clean after soft field landings. (See 4.9)

Tow Release:

Clean tow release. After a gear up landing check cable deflectors. Damaged parts must be replaced before the next take off.

Issued May, 1985

TN 301/12

23

Inspections

In addition to the inspections listed in item 6.4 the following inspections have to be accomplished:

Airbrake torque tube in the fuselage

On every annual inspection the airbrake torque tube in the fuselage must be inspected according to TN 301/18, working instruction no.2.

Airbrakes

On every annual inspection the airbrakes must be inspected according to TN 301/18, working instruction no.1.

6.5 Removal of the Water Ballast Tanks

Tie a piece of nylon cord (3mm) diameter and at least 5 m long, to the nylon cord sticking out of the wing root rib. Unscrew the screw cap of the valve. Pull the valve body with the tank out of its suspension in direction of the wing tip. Then pull the valve body and tank out of the wing through the opening in the root rib. Unknot the nylon cords from the tank and open the hose clamp at the valve. Attach the new tank and install it analogous. Fill the tank and check for watertightness.

6.6 Repair of Damage

Before every flight and especially after a period of nonuse, a thorough ground check should be carried out. Visually check the surface for small depressions, bubbles, and other unevenness. This could be a signal that something is not right.

Contact the manufacturer immediately and, if possible, send a photo of the damage and a report by a licensed airframe mechanic. The manufacturer will be able to supply the correct advice and a repair program saving you the time and troubles of quesswork and bad tries.

Minor surface damage such as scratches, gouges, and cracks in the finish may be repaired by a licensed airframe mechanic. (See also page 31). Knowledgeable advice can also be found in the Petite Plane Patch Primer. A list of materials for the DG-100 and a check list for postaccident inspection is found on pages 27-29.

Repairs by the owner should not be attempted if:

The spar flange is damaged.

The main fittings on the wings, fuselage, or tail are torn out or if in the immediate vicinity there are white areas in the laminations.

The parts are torn in such a way as to make repairs uncertain without the use of jigs or appliances.

The damage is so extensive that the original shape or contour is obscured.

Or if it would be necessary to cut away undamaged areas to gain access to damaged areas.

6.7 Service and Care

You have chosen a sailplane made of fiberglass which, though elegant, is enormously strong and robust.

A few tips for care of the surface:

- o Wash the surface only with clear water using a sponge and chamois.
- o Never use gasoline, alcohol, or thinner for cleaning.
- o Do not use detergent too often.
- o The surface may be polished as often as desireable. When using a power buffer, care must be taken that the surface is not overheated.
- o This sailplane should be protected from moisture just like other sailplanes.
- o The surface should be protected from intense sunlight (heat) and ballast should not be retained for extended periods.

6.8 Lubrication

Periodically, make a detailed inspection of the sailplane and lube all bearings. Especially the ball bearing univers joints should be cleaned and lubed (Molycoat Long-life). These areas are involved:


- o Aileron drive directly accessable at the wing contour break.
- o Spoiler drive in the spoiler box. In this location are the spoiler bearings which should be lubed.
- o Unscrew the push rod fairing on the left bulkhead and lube the guides.
- o Remove the storage area deck. Stabilizer, aileron, trim, and water ballast control rods should be lubed.

Subject: Hotellier control quick connects

Concerning: DG-100 (G), DG-100 (G) ELAN
DG-200, DG-200/17, DG-200/17C
DG-400
all serial no's

Reason: The sliding latch of the quick connect may loose its nonreversibility due to lubricants. This is most important for the airbrake control hook up.

- Measures:
1. When servicing the Hotellier quick connects be careful only to grease the ballseat.
 2. Clean the sliding latch with Aceton or similar degreasing agent. Operate the latch several times to make sure that no lubricant rests at the latch. Repeat this measure at least one time a year and after greasing the ballseat.
 3. For your own safety it is recommended to fit a diameter 1 mm spring pin (500 30 771) into the control hole.
At older aircraft it may be necessary to enlarge the control hole with a diameter 1,2 mm drill.
 4. Please file this service information next to the greasing programme in the manual of your DG.



Bruchsal 4, July 15, 1986

W. Chelmer

- o Open fuselage access cover. Lube sopliler control and flight control quick-disconnects.
- o Remove stick mechanism cover. Lube stick mechanism.
- o Lube guide of rudder adjustment mechanism.
- o Oil bearing points of gear struts in wheel well.
- o Lube the guide of the gear lever with Vaseline.
- o Clean and lube all hinges (elevators, rudder, ailerons, trim)

Single piece canopy

- o Take off the canopy and clean and grease the locking mechanism. After reinstalling the canopy, check the pilot force needed for emergency release with the red ball handle using a spring balance.
The force should not exceed 200 N (44 lbs.).
- o Check the canopy emergency release referring to flight manual page 9a.

6.9 Material List

List of materials used in the DG-100

Resin: Shell Epikote 162

Catalyst: BASF Laromin C 260
Mixing proportions 100parts resin: 38 parts
catalyst by weight or 2 parts resin: 1 part
catalyst by volume.

Fiberglass Fabric:

Interglas No.	US No.	Weave	Weight (grams/sg. meter)
90070	1610	Linen	80
92110	-	Twill	163
92125	-	Twill	280
92130	-	Linen	390
92145	181-150	Unidirectional	220

All fabrics - finish I 550

Rovings:

Gevetex EC-10-80-2400 K 43 with Silanschlichte

Foam:

Continental Conticell C 60 Color - brown
Röhm GmbH Rohacell 51 Color - white

Lacquer:

Lesonal PE Schwabbellack Mixing ratio 100 : 2

Filler:

The resin catalyst mixture may be thickened with chopped cotton fibers. Non-thickened resin and catalyst mixture is applied to the area first as a bonding layer then the thickened mixture may be used.

6.10 Check List After Suspected DamageEntire Aircraft:

Inspect the general alignment along the longitudinal axis (vertical and horizontal tail surfaces)

Wing-flex characteristics , wing angles and measurements in agreement with previously mentioned specs.

Wings:

Spar pins: Check for deformation in main pins and bushings and also white spots around bushings.

Wing root rib: Separation between rib and wing shell or between rib and main spar?

If necessary, remove paint and putty to determine if cracks extend into FRP.

Check for white spots and delaminations around bushings.

Shell: Compression fractures, cracks, blisters?

Spanwise, hair-line cracks in the leading-edge near the stagnation point can be ignored.

Ailerons: Compression fractures, cracks, blisters?

Check hinges and drives.

Check list

Fuselage:

Fuselage to wing connections:

White spots, excessive play, bent tubes (hard assembly)?

Fuselage and vertical stabilizer intersection: Cracks?

Scrape away paint and putty. While moving vertical stabilizer side to side and fore and aft, check for cracks extending into GFRP.

Stabilator mounting: Excessive play? Check top rib of vertical stabilizer for cracks especially near fittings.

Rudder bearings: Excessive play, white spots in FRP, bent fittings, cracks in finish?

Tail wheel: Enlarged axle hole? If so, fill with thick filler.

Fuselage shell:

Outside: Cracks, creases, nicks?

Inside: White spots, sharp white zig-zag lines, cracks? Any loose ribs?

Has any bulkhead become loose? To check this remove also the control column boot, instrument panel cover and the access cover of the tow hook compartment and check the bulkheads in this areas carefully.

Torsion check: Hold fuselage steady and attempt to move vertical stabilizer - does it move easier than usual?

If so, are the cracks visible?

Landing gear:

Check for straight axle, bent struts, alignment, ease of operation, over center locking? Is dirt in the forks of the forward strut?

White spots or cracks in the wheel well bulkheads.

Remove deck of storage area and inspect wheel well.

Gear lever condition?

Tow hook:

Especially after a belly landing check for dirt, function and if housing loosened or separated from fuselage.

Seat back rest bulkhead:

Cracks? Shoulder strap connection?

Seat belt:

Check for white areas near fuselage attachments.

Stick:

Check suspension. Excessive play?

Controls:

Condition and proper operation of all flight controls and all other operating devices.

Instruments:

Function? Dirt in the pitot plenum?

For further checks see page 23.

6.11 Repair instructions

I. The following can be repaired:

1. All damage to paint and putty.
2. Holes on the belly of the fuselage if the maximum diameter does not exceed the following:

Forward fuselage 80 mm
Aft boom 40 mm

Cr Cracks in the belly maximum length:

Forward fuselage 120 mm
Aft boom 80 mm

The blind glue joints of the fuselage boom should not be damaged.

3. Holes, cracks, blisters in the wings, tail, and control surfaces not in excess of the following dimensions:

	Diameter	Length
Wings	100 mm	150 mm
Stabilator	50 mm	80 mm
Aileron	50 mm	80 mm
Rudder	50 mm	80 mm

The parts may not be damaged in the spar area.

4. Replacement of bent fittings.

II. Method of FRP repairs (2,3 above)

1. Remove damaged fabric, bevel edges and roughen surface around hole.
2. All repairs must follow the procedure of wet over dry.

Special tips for handling FRP repairs are found in the Petite Plane Patch Primer.

3. The following overlap dimensions are to be maintained.

Control Surface Mass Balances

After the repair of any control surface, the mass balancing must be checked.

Rudder:

Disconnect control cables and lie fuselage on its side so that stabilizer is horizontal. At a point 200 mm (7.87 in.) from hinge line, lift rudder with small scale. If the scale reads more than 450 g (1 lb.), correct by adding metal strips to mass balance until the scale reads less than 430 g (0,95 lbs.)

Aileron

Suspend the aileron freely at hinge line and lift 180 mm (7.09 in.) from hinge line with scale. If scale reads more than 388 g (0,85 lb.), the mass balance must be increased.

Elevator:


Suspend the elevator freely at hinge line and lift 150 mm (5.9 in) from hinge line with scale. Scale must not read more than 650 (1.4 lb.).

With the stick fixed in a neutral position, the play in the aileron 188 mm from the hinge line should be ± 1.5 mm and the aileron should be neutral.

With the aileron fixed, the play in the stick at the top should be ± 3 mm.

Elevator play:

The play at the top of the control stick must not exceed 3 mm when the elevator is firmly held neutral position. There shall be no play in the automatic elevator control self connection mechanism. If necessary you can reduce the play by turning in the adjustment screw.



Rudder play:

The maximum allowable vertical play in the rudder hinges is 0,5 mm measured at the top hinge.

5. Compass

<u>Manufacturer</u>	<u>Type</u>
Bohli	46 MFK 1
PZL	B-13 KJ
Ludolph	FK 16

The compass is to be compensated in the glider.

6. Variometer

<u>Manufacturer</u>	<u>Type</u>
Winter	StV 55 (Ø 58)
Winter	StV 5 (Ø 80)
Winter	5 StVL (10.230/11)
Winter	5 StVLM (10.230/12)
Winter	5 StV (10.230/13)
Winter	5 StV M (10.230/14)
PZL	PRO 4 (Ø 58)
PZL	PRO 03 (Ø 80)

7. Turn and bank indicators

<u>Manufacturer</u>	<u>Type</u>
Apparatebau Gauting AOA	WZ-402/31 12 V (10.241/8)
PZL	EZS-3

or a certified artificial horizon

<u>Manufacturer</u>	<u>Type</u>
Winter	6 FMS 4 (10.210/10)
Winter	6 FMS 5-2 (10.210/3)
PZL	PSO 6
PZL	PR-400 S

The airspeed indicator must have the speed range markings see Flight manual page 6.

2. Altimeters

<u>Manufacturer</u>	<u>Type</u>
Winter	4 FGH 10
PZL	PW 12

E. Inspection Procedure For Increase Of Service Time

1. General

The results of fatigue tests of wingspar sections have demonstrated recently that the service time of GFRP gliders may be extended to 6000 hours, if for each individual glider (in addition to the obligatory annual inspections) the airworthiness is demonstrated according to a special multi-step inspection program particularly with regard to the service life.

2. Dates

When the glider has reached a service time of 3000 hours, an inspection must be done in accordance with the inspection program mentioned under point 3. If the results of this inspection are positive or if any defects found have been duly repaired, the service time of the glider is extended by another 1000 hours to a total of 4000 hours (first step).

The above inspection program must be repeated when the glider has reached a service time of 4000 hours. If the results of this inspection are positive or if any defects found have been duly repaired, the service time of this glider is extended to 5000 hours (second step).

When the glider has reached a service time of 5000 h the above inspection program again must be repeated. If the results of the inspection are still positive, or if any defects found have been duly repaired, the service time may be extended to a total of 6000 hours (third step).

For a possible service time exceeding 6000 hours procedures will be evaluated in the future.


3. LBA-approved Glaser-Dirks Flugzeugbau GmbH document No.XXXX (to be issued and approved in the future) contains the structural inspection procedures and limitations to be used for extending the service life above 3000 flight hours.
4. The inspection must only be done by the manufacturer or by a licensed repair station or inspector.
5. The results of the inspection have to be recorded in an inspection test report wherein comments are required for each inspection instruction. If the inspections are done outside the manufacturer's facilities, a copy of the records must be sent to the manufacturer for his evaluation and information.
6. The annual inspection is not affected by this inspection program.

DG-100-G

High performance sailplane

FAI Standardclass

Diagram 3




Technical Data

wing span	15 m ²
wing area	11 m ²
aspect ratio	20,5 m
length	7 m
fuselage width	0,62 m
fuselage height	0,81 m
empty weight	230 kg
water ballast	100 kg
max. take off weight	418 kg
wing loading G/F	28-38 kg/m ²
max. speed V	260 km/h
Stall speed (G/F = 28 kg/m ²)	60 km/h
minimum sink Ws (G/F = 28 kg/m ²)	0,59 m/s
at	74 km/h
best glide ratio (G/F = 38 kg/m ²)	1:39,2
at	105 km/h
Simple aerobatics permitted	

Glaser-Dirks Flugzeugbau GmbH, 752 Bruchsal-Untergrombach, Im Schollengarten 19-20, West Germany, Tel.: 07257/1071

Airspeed Calibration DG-100



The airspeed indicator utilizes the forward static ports

Examples for calculating the water ballast

	1	2	3	4
Emptyweight (page 21) — kg (lb)	235 (518)	240 (529)	240 (529)	240 (529)
Pilot and parachute —	75 (165)	90 (198,5)	105 (231,6)	115 (253,7)
Baggage —	5 (11)	8 (17,6)	20 (44)	30 (66)
Waterballast —	100 (220)	80 (176,5)	34 (75)	-
Take off weight —	415 (915)	418 (922)	399 (880)	385 (849)

Max. take off weight without water ballast — 385 kg (849 lb)

Max. take off weight with minimum 80 kg (176 lb) water ballast — 418 kg (922 lb)





Diagram 5

Placard Locations

Diagram 6




Glaser-Dirks Flugzeugbau GmbH			
Model: DG-100		Factory No:	
<u>Maximum airspeeds</u>			
Never exceed (V_{NE})	260 km/h.	162 mph	140 kts
In rough air (V_R)	260 km/h.	162 mph	140 kts
Maneuvering (V_A)	165 km/h.	103 mph	89 kts
On zero-tow (V_T)	165 km/h.	103 mph	89 kts
On winch tow (V_W)	130 km/h.	81 mph	70 kts
Landing gear extended	165 km/h.	103 mph	89 kts
Spoilers	260 km/h.	162 mph	140 kts
<u>Gross weight</u> 418 kg. (922 lb.) including water ballast.			
If the pilot's weight with the parachute is below 75 kg. (165 lb.) ballast weight must be installed in the trim weight holder or in the seat. (See Flight Manual).			
<u>Operating Limitations</u>			
The sailplane must be operated in compliance with the operating limitations as stated in the form of markings, placards and Flight Manual.			
Cloud flying is only permitted when the following instruments are installed: airspeed indicator, altimeter, magnetic compass, turn and slip indicator and variometer.			
<u>Approved aerobatic maneuvers</u>			
<u>Maneuver</u>	<u>Recommended entry speed</u>		
Looping, chandelle, stall turn	170 km/h. 106 mph 92 kts		
Spin	Use slow deceleration		
Maximum load factor - at maneuvering speed: +5,3/-2,65			
at never exceed speed: 4,0/-1,3			
All aerobatic maneuvers including spins must be accomplished in accordance with the approved DG-100 Flight Manual.			
Night flying is prohibited.			

Placards on the rear bulkhead:

- fire proved placard
- Serial No. RU
- Baggage: max. 66 lbs
- on the left gear door
- tire pressure 36 p.s.i.
- rated load 1100 lbs.
- Front surface of main wing spa
- Serial No. FL left
- " " FR right
- Aileron inner main spar surface
- Serial No. QL left
- " " QR right
- stabilizer actuating arm
- Serial No. HL
- Rudder gusset
- Serial No. SR
- above the tail wheel 28 ps.i.

DG-100

Difference in placarting for single piece canopy.



[REDACTED]

Höhensteuerung
elevator control
DG - 1006




Diagram 8

29,980





Diagramm 9

21.4.79

Querruder- und Bremsklappensteuerung
aileron and airbrake controls

DG-100

Diagram 10



Glaeser-Dirks Flugzeugbau GmbH
Postfach 4120, PLZ D-7620
Tel. 07251-13-0, Fax 89 22
Im Schwanengarten 18-20
D-7620 Bruchsal-Untergombach
LBA-Zertifikat: Herstellungsbericht 18 25
LBA-Zertifikat: Luftfahrttechnische Zeichnung 84 278

Technical note
No. 301/17, 323/8, 359/18,
No. 826/31, 348/7, 370/5,
No. 866/4, 384/3, 873/7

Page 1 from 1

- SUBJECT : Seat Harness
- EFFECTIVITY : DG-gliders and motorgliders
on request
- ACCOMPLISHMENT : with installation of new harness
- REASON : Some newer types of harnesses are not
listet in the maintenance manuals of
all DG-types.
- INSTRUCTIONS : 1. The following newer types are accept-
able for installation: Certification No.
Gadringier BAGU 5202 G 40.070/32
" SCHUGU 2700 G 40.071/05
rubber coated adjuster bars
Autoflug BAGU FAG-12 D-O 40.070/47
" SCHUGU FAG-12 H-O 40.071/25
Schroth 4-01-0 104 40.073/11
Install the new harness similar to the
existing harness.
2. If you install one of these types, file
this TN as enclosure into your aircraft
maintenance manual.
3. Enter the new harness in the equipment
list of your aircraft or write a new
equipment list.

REMARKS : The instructions may be executed by the
owner.
They are to be inspected and entered in
the aircraft logs by a licensed inspector.

Bruchsal 4, date
Jan. 24, 1996

Author: W. Dirks

W. Dirks

LBA - approved:
The German original of this TN has
been approved by the LBA under the
date 08.4.1996 and is signed by
Mr. Fendt. The translation into Eng-
lish has been done by best knowledge
and judgement.

Type certification inspector:

D. Lange